

## EN2532 Robot Design and Competition

## Laboratory Sheet-Practical No: 4

Indexes:	210258J 210542B 210069F 210418C 210174X 210205V	Date:	10 / 7 / 2023
Name:	Team Cosmo	Group No:	06

- Comment on your observations of the sensor readings and how you can obtain the distance value according to the particular reading.


Ultrasonic sensors calculate distance by measuring the time taken for sound waves to bounce back from an object and using the formula

`duration = pulseIn(echoPin, HIGH); //Returns the length of the pulse in microseconds`

`distance = (duration / sec_to_microsec) * (speed_of_sound * meter_to_cm) / 2.0;`

The distance didn't depend on the type of material of the surface used.

- Place objects of different size at the same distance from the sensor and identify the minimum dimensions of the object that is detected by the sensor. 1.5 cm
- Place a cardboard sheet at a fixed distance with different ultrasound wave incident angles ( $\theta$ ) with the sensor and observe the measurement. Vary  $\theta$  from  $0^\circ$  to  $70^\circ$  at steps of  $10^\circ$ .



- Comment on your observations.

$0^\circ$  - 30 cm

$40^\circ$  - 115 cm

$10^\circ$  - 30cm

$50^\circ$  - 115 cm

$20^\circ$  - 115 cm

$60^\circ$  - 115 cm

$30^\circ$  - 115 cm

$70^\circ$  - 115 cm

We noticed an steep increase in measurement errors as the angle exceeded 15 degrees.

- Place an object with minimum detectable dimensions. Then vary the angle from  $60^\circ$  to  $0^\circ$  in steps of  $10^\circ$  and obtain the maximum object detectable distance of the sensor for each angle and plot them in the given graph below,

